APERTURE-24-TRIMLESS INSTALLATION MANUAL
APR24

YYZ LIGHTING

IP 20/IP54 CE

INSTALLATION INSTRUCTION

1. Support structure
2. Fastner
3. Power Connection
4. Profile
5. Gear Tray
6. Diffuser

Fitting **1**

Remove conseal end plate (if fitted) **2**

Remove diffuser **3**

Remove gear tray **4**

Note: Drill holes at 3meter Maximum center

Drill through top section of the luminaire to accomodate selected fixing screw **5**

CAUTION: Make sure that the profile is not distorted by overtighting the fastner

Fix screw or selected fastener into support structure **6**